



***IMPORTANT !!!! Read this manual before
attempting any handling or installation of the meter.***



Disclaimer

The user/purchaser is expected to read and understand the information provided in this manual, follow any listed Safety Precautions and Instructions and keep this manual with the equipment for future reference.

The information in this manual has been carefully checked and is believed to be entirely reliable and consistent with the product described. However, no responsibility is assumed for inaccuracies, nor does Badger Meter Incorporated assume any liability arising out of the application and use of the equipment described.

Should the equipment be used in a manner not specified by Badger Meter, Incorporated, the protection provided by the equipment may be impaired.

Questions or Service Assistance

If you have questions regarding the product or this document contact:

Badger Meter, Incorporated
P.O. Box 245036
Milwaukee, WI 53224-9536

Telephone: (414) 355-0400, (877) 243-1010

Fax: (866) 613-9305

On the Web: www.badgermeter.com
or call your local Badger Meter representative.

Product Identification Information

Record the product identification numbers from the nameplate.

Modular Mag Meter

Model Number _M-3000_____

Serial Number _____

Tag Number _____(if applicable)

TABLE OF CONTENTS

Disclaimer	2
Questions or Service Assistance.....	2
Product Identification Information	2
SAFETY PRECAUTIONS and INSTRUCTIONS	4
Equipment Unpacking, Inspection, Moving and Return Policies	4
Rigging, Lifting, Moving Large Units.....	4
Instructions Specific to Hazardous Area Installations	5
METER DESCRIPTION	6
Empty Pipe Detection.....	6
Amplifier Mounting Options	6
Meter Mount	6
Remote Mount.....	6
METER/AMPLIFIER LOCATION, ORIENTATION and APPLICATIONS	6
Remote Amplifier Outdoor Location	6
Temperature	6
Pipelines and Fluid Flow.....	7
Meter Orientation.....	7
Vertical Placement.....	7
Horizontal Placement	7
Straight Pipe Requirements.....	7
Pipe Reducer Requirements	7
Chemical Injection Applications.....	8
Partially Filled Pipe Situations	8
Meter Gaskets and Grounding	9
METER INSTALLATION	9
Remote Mount Amplifier	10
Remote Mount Amplifier/Detector Wiring	10
Detector Junction Box.....	10
Remote Mount Wiring Diagram	11
Electrode and Coil Wiring from Detector Junction Box to Remote Mount Amplifier Junction Box.....	12
Electrode Wiring	12
Coil Wiring	12
Output Wiring.....	13
NEMA 6P (IP67) Protection.....	13
External Disconnect	16
AC/DC Power Wiring	16
Adjustable Display/Control Card.....	16
AMPLIFIER CONTROLS, CONTROL METHODS AND DATA DISPLAY PROGRAMMING	17
Card Display and Controls.....	17
Two Programming Methods.....	18
Main Screen(s)	18
Password.....	19
Amplifier Access Switches/Buttons	19
How to Program.....	20
What to Program	23
PROGRAMMING REQUIRED PARAMETERS.....	23
Input a Password.....	23
Set Flow Units	24
Set Full Scale Flow.....	24
Set Low Flow Cutoff	24
Set Flow Direction	25
Set Damping Factor.....	25
Empty Pipe Calibration	25
Pulse Output.....	26
Analog Output.....	28
DETECTOR SPECIFICATIONS	30
AMPLIFIER SPECIFICATIONS	31
MAINTENANCE	32
Flow Tube and Electrode Cleaning	32
Fuse Replacement	32
Amplifier PCB Stack Replacement	33
FLOW CHART - MENU STRUCTURE.....	35

SAFETY PRECAUTIONS and INSTRUCTIONS

Safety considerations are emphasized by the placement of safety symbol icons on the product or next to important text, pictures or drawings throughout this manual. The symbols are:



When and where this symbol is attached to the product it indicates a potential hazard. It means that documentation must be consulted to determine the nature of the potential hazard and any actions that need to be taken.

⚠ WARNING

Warning indicates an action or procedure, which, if not performed correctly, can result in severe personal injury, death, or substantial property damage. Comply with the instruction and proceed with care.

⚠ CAUTION

Caution indicates an action or procedure, which if not performed correctly, will or can cause minor personal injury or property damage. Comply with the instruction and proceed with care.

Equipment Unpacking, Inspection, Moving and Return Policies

1. If shipping container damage is evident at delivery, have a responsible person present when the meter is unpacked.
2. Inspect the shipping container for unpacking, lifting or moving instructions.
3. As the unit is opened and unpacked, verify the shipment packing list and your order form match the items in the shipment.
4. Open the container and remove all cushioning materials. Keep the shipping container and packing materials should the meter need to be returned or put in storage.
5. Remove the meter from the container. For meter flow tube diameters between 2" and 8" (50 and 200mm) use a crane or lifting device with soft straps placed around the detector body, at the flanges. For meter flow tube diameter sizes 10" (250mm) and larger, lift the unit via the lifting lugs with a crane, cables and hooks.
6. Inspect the meter for signs of shipping damage; scratches, loose or broken parts.

NOTE: If damage is found, a formal claim for damage in transit is the responsibility of the customer. Within 48 hours of delivery request an inspection report from the carrier. File a claim with the carrier. Contact the Badger Meter factory to facilitate repair or replacement, 877-248-1010.

7. All detectors with PTFE liners are shipped with a liner protector to maintain proper form of the PTFE material during shipping and storage.

NOTE: Do not remove the liner protector until installation.


8. Storage: If the meter is to be stored, place it in its original container in a dry, sheltered location. Storage temperature ranges are: -4°F to 158°F (-20°C to 70° C).

Rigging, Lifting, Moving Large Units

DO NOT lift or move a meter via its amplifier, junction box or cables.


⚠ CAUTION

Lift and move meters with flow tubes between 2" and 8" (50 and 200mm) with a crane rigged with soft straps. Place a strap around the detector body, between the flanges, on each side of the detector.




⚠ CAUTION

Lift meter flow tube diameter sizes 10" (250mm) and larger via its lifting lugs. Use the proper size crane, cables and hooks. **DO NOT** lift the meter by the amplifier or, on remote style meter, by the junction box.




⚠ CAUTION

Use the sling-rigged method to lift large detectors into a vertical position while still crated. Use this method to position large detectors vertically into pipelines.




⚠ CAUTION

Do not lift a detector with a forklift via the detector body between the flanges. The housing could be dented and/or damage caused to internal coil assemblies.



⚠ CAUTION

NEVER place forklift forks or rigging chains, straps, slings, hooks or other objects inside or through the detector flow tube for lifting or handling purposes. The isolating liner could be damaged, rendering the unit inoperable.



Instructions Specific to Hazardous Area Installations

These instructions apply to equipment covered by FM Certificate Number IAB-182-01.


1. The temperature range for fluids passing through the detector is -4°F to $+248^{\circ}\text{F}$ (-20°C to $+120^{\circ}\text{C}$).
2. The ambient temperature range surrounding the amplifier is -4°F to $+122^{\circ}\text{F}$ (-20°C to $+50^{\circ}\text{C}$).
3. The ambient temperature range surrounding the junction box must not exceed 122°F (50°C).
4. During any installation or repair, perform all procedures in accordance with the applicable code of practice.
5. Suitably trained personnel shall perform all installation or repair procedures.
6. If the equipment is likely to come into contact with aggressive substances, it is the responsibility of the user to take suitable precautions that prevent it from being adversely affected, thus ensuring that the type of protection is not compromised.

Aggressive Substances – e.g. acidic liquids or gases that may attack metals, or solvents that may affect polymeric materials


Suitable Precautions – e.g. regular checks as part of routine inspections or establishing, from the material's data sheet that it is resistant to specific chemicals

Additional Information


Certification markings are noted on the product label. Markings include:




Mounted amplifier 85-240 VAC



Remote mount 85-240 VAC



Mounted amplifier 24 VDC



Remote mount 24 VDC

For additional information regarding importation, equipment installation, equipment repair, equipment return or renewal parts, please contact:

Badger Meter, Incorporated
P.O. Box 245036

Milwaukee, WI 53222

Telephone: (414) 355-0400

Fax: (414) 355-7499

On the WEB: www.badgermeter.com or contact your local Badger Meter representative

METER DESCRIPTION

Badger® Model M-3000 electromagnetic meters are FM approved for Class I, Div 2 hazardous locations. To achieve hazardous location ratings electrodes in the flow tube are Intrinsically Safe, designed according to Factory Mutual (FM) standards. Those standards limit the amount of energy that can be sent to electrodes to prevent a spark from occurring.

Empty Pipe Detection


Badger Model M-3000 meters are equipped with an Empty Pipe Detection feature. Empty Pipe Detection is accomplished by positioning a third electrode close to the 12 o'clock position. Any time this electrode is not covered by fluid, for a minimum of five seconds, the meter displays an Empty Pipe Detection condition, sends out an error message if desired, and stops measuring to maintain accuracy. When the electrode is again covered with fluid, the error message disappears and the meter continues measuring.

Amplifier Mounting Configuration Options

Two amplifier-mounting configuration options are available to meet a variety of meter placement and environmental conditions.

Meter Mount Configuration

The **Meter Mount** configuration has the amplifier mounted directly on the detector. This compact, self-contained configuration minimizes installation wiring.



Meter Mount

Remote Mount Configuration

Remote Mount configuration places the amplifier and its functions at a location separate from the fluid flow and detector. This configuration is necessary in situations where process fluid temperature or environment exceeds amplifier ratings. A remote mounting bracket is supplied.

Detector and amplifier are connected by wires, run through conduit, between junction boxes on the detector and remote mounted amplifier. The distance between the detector junction box and amplifier junction box can be up to 100 feet (30m).

This configuration can also provide a more convenient amplifier programming and display placement for monitoring meter readings.



METER/AMPLIFIER LOCATION, ORIENTATION and APPLICATIONS

Remote Amplifier Outdoor Location

The amplifier can be installed and operated outdoors. However, protection from the elements must be considered:

1. Be aware of the ambient environment and temperature ratings for the unit -4°F to 122°F (-20°C to 50°C).
2. If an indoor location is within 100 feet (30m) of the detector installation, consider increasing the cable length and mounting the amplifier indoors.
3. At a minimum, fabricate a roof or shield over and/or around the amplifier to protect the LCD display screen from sunlight.

Temperature

To prevent meter damage in any environment, minimum and maximum temperature ranges must be observed.

1. For remote amplifier applications, the fluid temperature range is -4°F to 248°F (-20°C to 120°C) at a maximum ambient temperature of 122°F (50°C) for the following liner materials: PFA, PTFE and Halar®.
2. For remote amplifier applications, the fluid temperature range is 32°F to 178°F (0°C to 80°C) at a maximum ambient temperature of 122°F (50°C) for the following liner materials: Hard rubber and soft rubber.
3. For meter mounted amplifier applications, the fluid temperature range is -4°F to 212°F (-20°C to 100°C) at a maximum ambient temperature of 122°F (50°C) for the following liner materials: PFA, PTFE and Halar.
4. For meter mounted amplifier applications, the fluid temperature range is 32°F to 178°F (0°C to 80°C) at a maximum ambient temperature of 122°F (50°C) for the following liner materials: Hard rubber and soft rubber.
5. The ambient temperature range surrounding the amplifier is -4°F to 122°F (-20°C to 50°C.)
6. The ambient temperature range surrounding a remote junction box mounted to the detector is -4°F to 248°F (-20°C to 120°C.)

Pipelines and Fluid Flow

Pipeline and fluid flow conditions that should be avoided:

1. Do not install the meter where extreme pipe vibrations exist. If vibrations are present, secure piping before and after the meter with appropriate pipe supports. If vibrations can't be restrained, consider mounting the amplifier remotely.
2. Avoid installing the detector close to pipeline valves, fittings or impediments that can cause flow disturbances.
3. For detectors with PTFE liners, avoid installing the detector on suction sides of pumps.
4. Avoid installing the detector on outlet sides of piston or diaphragm pumps. Pulsating flow can affect meter performance.
5. Avoid locations near equipment producing electrical interference such as electric motors, transformers, variable frequency, power cables, etc.

6. Verify both ends of the signal cables are securely fastened.
7. Place power and signal cables in separate conduit.
8. Place the meter where there is enough access for installation/maintenance purposes.


Meter Orientation

Mag meters can operate accurately in any pipeline orientation and can measure volumetric flow in forward and reverse directions.

NOTE: A Forward Flow direction arrow is printed on the detector label.

Vertical Placement

Mag meters attain optimal performance when placed vertically, with liquid flowing upward and meter electrodes in a closed, full pipe.




Vertical placement allows the pipe to remain completely full, even in low flow, low pressure applications and it prevents any solids build-up or sediment deposit or accumulation on the liner and/or electrodes.

NOTE: Carefully observe the "Forward Flow" label on the meter body and install the meter accordingly.

Horizontal Placement


In a horizontal piping orientation, mount the detector to piping with the flow measuring electrode axis in a horizontal plane (3 and 9 o'clock).

This arrangement prevents solids build-up or sediment deposit or accumulation on the electrodes.



Straight Pipe Requirements

Sufficient straight pipe runs are required at the detector inlet and outlet for optimum meter accuracy and performance. An equivalent of three (3) diameters of straight pipe is required on the inlet (upstream) side. Two (2) diameters are required on the outlet (downstream) side.




Pipe Reducer Requirements

With pipe reducers a smaller size meter can be mounted in larger pipelines. This arrangement may increase low flow accuracy.


There are no special requirements for standard, concentric, pipe reducers.

Custom fabricated pipe reducers must have an approximate slope angle of 15 degrees to minimize flow disturbances and excessive loss of head. If this is not possible, install the custom pipe reducers as if they were fittings and install the amount of straight pipe stated previously.




Chemical Injection Applications

For water line applications with a chemical injection point, install the meter upstream of the injection point. This eliminates any meter performance issues.



If a meter must be installed downstream of a chemical injection connection, the recommended distance between the meter and the injection point must be significant; 50 to 100 feet (15 to 30 meters). When the water/chemical solution reaches the meter it must be a complete, homogeneous mixture. If the injection point is too close, the meter senses two (2) different liquids (conductivity is different for each) and correct data output cannot be assured. The injection method:

spaced bursts, continuous stream of drips, a liquid or gas can also affect downstream readings by the meter.




Sometimes it's difficult to specify the exact downstream placement distances because of the number of variables. Contact Badger Meter Technical Support, 877-243-1010, to review your application if necessary.


Partially Filled Pipe Situations

It is possible to encounter situations where the process pipe is momentarily only partially filled. Examples include; lack of backpressure, insufficient line pressure, gravity flow applications, etc.


To eliminate these situations:





Do not install the meter in the highest point of the pipeline



Do not install the meter in a vertical, downward flow section of pipe.



ALWAYS locate ON/OFF valves on the downstream side of the meter



To minimize the possibility of partially full pipe flows in horizontal, gravity or low pressure applications, create a pipe arrangement that insures the detector remains full of liquid at all times

Meter Gaskets and Grounding

Two other considerations to meter location, orientation and application are gasket and grounding requirements and placement.

Meter/Pipeline Connection Gaskets

Gasket(s) (not provided) must be installed between the detector isolating liner and the pipeline flange to ensure a proper and secure hydraulic seal. Use gaskets compatible with the fluid flow. Center each gasket on the flange to avoid flow restrictions or turbulence in the line.

Do not use graphite or any electrically conductive sealing compound to hold gaskets during installation. Measuring signal accuracy could be affected.

If a grounding ring is used in the detector/pipeline connection, place the ring between two gaskets. (See **Non-Conductive Pipe Grounding** section.)

Meter Grounding

Process pipeline material can be either electrically conductive (metal) or not electrically conductive (made of or lined with PVC, fiberglass or concrete).


CAUTION

To ensure proper unit operation, the mag meter impact ground (zero voltage reference) must be connected to the liquid media and to a good, solid earth ground. Perform grounding procedures after the meter is connected to the pipeline.

Conductive Pipe Grounding

A grounding bolt is located on each mag meter flange. Drill and tap the pipeline flanges on each side of the meter and install a grounding bolt to each.

To ground the unit, attach a ground strap (provided) of copper wire, at least 12AWG size, between the grounding bolts on the meter flanges and the bolts on the pipeline flanges. Do this on the inlet and outlet sides of the meter.





Non-Conductive Pipe Grounding

If the process pipeline material is not electrically conductive and your meter was not ordered with an optional grounding electrode, place a grounding ring (available from Badger Meter) between two gaskets on both ends of the meter.

GROUNDING RING INSTALLATION KIT

SUPPLIED HARDWARE INCLUDES:
2 GROUNDING RINGS
4 BOLTS
4 LOCK WASHERS
2 NUTS
2 GROUND STRAPS



After the grounding rings, gaskets and meter are assembled to the pipeline, attach ground straps (provided) of copper wire, at least 12AWG size, to grounding bolts on meter flanges and to the grounding rings.

If your meter was ordered with an optional grounding electrode, the use of grounding rings is not necessary.

METER INSTALLATION PLANS and EXECUTION

Plan meter layout, location and installation. During installation, remember these important points:

1. Heed all safety notifications.
2. Select a detector location with room for installation and maintenance procedures.
3. Use proper lifting, rigging, moving and procedures for large units.
4. Consider the meter environment; particularly ambient and process flow temperatures.
5. Consider the process pipeline (vibrations) and its flow characteristics (valve and pump locations).
6. Meter orientation to the pipeline (vertical or horizontal).
7. Straight pipe requirements.
8. Pipe reducer requirements.
9. Special applications and/or situations.

For Remote Mount Units consider:

1. Amplifier location.
2. Remote amplifier mounting bracket.
3. Proper conduit and conduit fittings.
4. Wiring and conduit locations.

REMOTE MOUNT AMPLIFIER


NOTE: Screws are supplied to attach the remote mount bracket to the amplifier. Screws are not supplied to attach bracket at mounting location.

Remote Mount Amplifier Location Requirements:

1. A sturdy and safe mounting surface capable of holding the amplifier weight (20 pounds, 9 Kg).
2. Within the allowable temperature range: -4°F to 122°F, (-20°C to 50°C).
3. Access to amplifier covers, ports, terminals, screen and adjustments.
4. As close to the detector as possible.
5. Determine length and route of cable/conduit runs.

Mount Bracket to Amplifier

1. Align bracket-mounting holes with amplifier mounting holes.
2. Attach bracket to amplifier with supplied screws. Torque screws to 80 in. lb.



Mount Bracket/Amplifier to Location


1. Position the bracket/amplifier in the desired orientation.
2. Secure bracket/amplifier to location.

REMOTE MOUNT AMPLIFIER/DETECTOR WIRING

Remote Mount Amplifier

The remote mount amplifier has three chambers and five wire ports. The Junction Box and Connections Chambers and wiring ports provide amplifier openings for wire, conduit, tool and hand access to amplifier terminal blocks. Detector to amplifier wires connect in the Junction Box Chamber. Amplifier AC power and customer signal wires attach in the Connections Chamber.


The Display/Programming Chamber provides access to fuses and circuit boards. They are discussed later.



(Refer to the Remote Mount Wiring Diagram on page 11.)


Detector Junction Box

The Detector Junction Box has one chamber and two wire ports. The Junction Box, Chamber and wiring ports provide openings for wire, conduit, tool and hand access to terminal blocks. Detector to remote mount amplifier electrode and coil wires connect to the detector through the chamber wire ports.



⚠ WARNING

- Suitably trained personnel shall perform all installation or repair procedures.
- Disconnect power to the unit before attempting any installation or maintenance.
- Do not bundle or route signal wires with power wires.
- Use proper conduit, connections and supplied cables in all wiring procedures.
- Observe all local applicable electrical codes when wiring any equipment.



REMOTE MOUNT WIRING DIAGRAM
CLASS 1 DIVISION 2, ZONE 2

Electrode and Coil Wiring From Detector Junction Box to Remote Mount Amplifier Junction Box

A remote mount unit requires electrode and coil cables, from the detector junction box to the amplifier junction box, be enclosed in properly rated conduit. Use conduit fittings (not supplied) that are rated for Class I, Div 2 hazardous locations.

⚠ WARNING

Failure to use proper conduit fittings rated for Class I, Div 2 hazardous locations, invalidates the FM rating and any warranties, expressed or implied, for this equipment.

1. Lay out the cable and conduit between the Detector Junction Box and the Amplifier Junction Box. Use Belden #9155 cable or equivalent for electrodes. Use Belden #8770 cable or equivalent for coils.
2. Run cables through the conduit, between Detector Junction Box and Amplifier Junction Box.
3. Place four Nema 6P, 1/2 inch NPT fittings on conduit.
4. Remove the four junction box wire port screws, two on each junction box.


Electrode Wiring in Detector Junction Box

To connect electrode wires in the Detector Junction Box:

1. Unscrew the Detector chamber cover. If necessary, use a strap wrench.
2. Remove the protective plastic cover to access the terminal block screws.

NOTE: Plastic cover must be reattached to maintain hazardous location rating.

3. Strip the cable jacket back 2 inches (50mm).
4. Strip the 4 wires back ¼ inch (6mm).
5. Thread wires through the proper cable access. Connect the wires to the compression style screw terminals of the Detector Junction Box.



Red to terminal labeled - E1
 Green to terminal labeled - SHLD
 Black to terminal labeled - E2
 White to terminal labeled - EP

Cable length, between Junction Boxes, may be up to 100 feet (30M).

6. Run cable and conduit to Amplifier junction box.


Electrode Wiring in Amplifier Junction Box

To connect the electrode wires in the Amplifier Junction Box:

1. Unscrew the amplifier junction box chamber cover. If necessary, use a strap wrench.
2. Remove the protective plastic cover to access the terminal block screws.

NOTE: Plastic cover must be reattached when wiring is complete to maintain hazardous location rating.

3. Strip the cable jacket back 2 inches (50mm).
4. Strip the 4 wires back ¼ inch (6mm).
5. Thread wires through the proper cable access. Connect the wires to the compression style screw terminals of the Amplifier Junction Box.



Red to terminal labeled - E1
 Green to terminal labeled - SHLD
 Black to terminal labeled - E2
 White to terminal labeled - EP


Coil Wiring in Detector Chamber

To connect coil wires in the Detector chamber:

1. Lay out the cable and conduit between the Detector Junction Box and the Amplifier Junction Box. Use Belden #8770 cable or equivalent for coils.

NOTE: Plastic cover must be reattached to maintain hazardous location rating.

2. Strip the cable jacket back 2 inches (50mm).
3. Strip the 2 wires back ¼ inch (6mm).
4. Thread wires through the proper cable access. Connect the wires to the compression style screw terminals of the detector chamber.




5. Connect conduit to junction box. Use a NEMA 6P ½ inch NPT fitting.
6. Install protective plastic cover over terminal blocks.
7. Attach detector chamber cover.

Cable length between Junction Boxes may be up to 100 feet (30M).

Coil Wiring in Amplifier Junction Box

To connect the coil wires in the amplifier junction box:

1. Strip the cable jacket back 2 inches. (50mm)
2. Strip the 2 wires back ¼ inch. (6mm)
3. Connect the wires to the compression style screw terminals of the amplifier junction box.



4. Connect conduit to junction box. Use a NEMA 6P ½ inch NPT fitting.
5. Install protective plastic cover over terminal blocks.
6. Attach the amplifier junction box chamber cover.

OUTPUT WIRING

The Badger® M-3000 Meter converts liquid flow into electrical signal(s). With proper output wiring and amplifier programming, the signal(s) are sent to, and used by, processing equipment used in operations or other procedures.

NOTE: Output wires and terminals are the same for meter mount or remote mount meters

Output wiring requires 18 to 22 AWG maximum, shielded wire (not supplied). Signal wire insulation temperature class should exceed the maximum temperature where installed (typical, 185°F, 85°C).

Use conduit and conduit fittings (not supplied) rated for Class I, Div 2 hazardous locations.

NEMA 6P (IP67) Protection

⚠ CAUTION

The flow meter will fulfill all the requirements regarding NEMA 6P (IP67) protection if the following points are observed:

1. For applications with detector mounted amplifier (amplifier is located in submersed location)

- Both screw-on cover gaskets must be clean and undamaged prior to screwing the covers onto the amplifier housing.
- Both screw-on covers of the amplifier housing must be screwed on tightly (note: hand tightening is sufficient, over tightening of the cover may result in damage to the covers or the housing).
- The four screws that attach the amplifier assembly to the detector neck must be firmly tightened.
- Cable glands that are screwed into the NPT connections located on the amplifier housing must be firmly tightened.
- Cable glands that are screwed into the NPT connections located on the amplifier housing must be approved for NEMA 6P (IP67) service. Additionally, the cable gland must be the correct size for the outside diameter of the cable being used. (note: if the cable gland is not the correct size for the outside diameter of the cable, the gland will not properly seal resulting in water infiltration).
- All cables must have a "drip loop" to prevent water from migrating down the cable into the cable gland.
- If a NPT connection is not used, then a plug equipped with thread sealant that is approved for NEMA 6P (IP67) must be used to fill the hole. (note: all three NPT connections of the amplifier housing come equipped from the factory with hole plugs incorporating approved thread sealant)
- If a conduit connection is required, then the conduit and the conduit hub must be approved for NEMA 6P (IP67) service.
- All NPT threads must have thread sealant that is approved for NEMA 6P (IP67) service applied to the threads prior to installation.

2. For applications with remote amplifier (amplifier is located in non-submersed location)

- The screw-on cover gasket of the junction box mounted to the detector must be clean and undamaged prior to screwing the cover onto the junction box housing.
- The screw-on cover of the junction box housing mounted to the detector must be screwed on tightly (note: hand tightening is sufficient, over tightening of the cover may result in damage to the cover or the housing)
- The four screws that attach the junction box assembly to the detector neck must be firmly tightened.
- Cable glands that are screwed into the NPT connections located on the junction box housing must be firmly tightened.
- Cable glands that are screwed into the NPT connections located on the junction box housing must be approved for NEMA 6P (IP67) service. Additionally, the cable gland must be the correct size for the outside diameter of the cable being used. (note: if the cable gland is not the correct size for the outside diameter of the cable, the gland will not properly seal resulting in water infiltration).
- All cables must have a "drip loop" to prevent water from migrating down the cable into the cable gland.
- If a NPT connection is not used, then a plug equipped with thread sealant that is approved for NEMA 6P (IP67) must be used to fill the hole. (note: both NPT connections of the junction box housing come equipped from the factory with hole plugs incorporating approved thread sealant).
- If a conduit connection is required, then the conduit and the conduit hub must be approved for NEMA 6P (IP67) service.
- All NPT threads must have thread sealant that is approved for NEMA 6P (IP67) service applied to the threads prior to installation.

⚠ WARNING

All of the above points must be strictly followed for NEMA 6P (IP67) service. Failure to comply could possibly result in an electrical hazard and/or damage to the flow meter.

Output Wire Connections

⚠ WARNING

- Properly trained personnel must perform all installation and/or repair procedures.
- Disconnect power to the unit before attempting any installation or maintenance.



To connect control signal wires:

1. Remove the connections chamber cover. If necessary, use a strap wrench.
2. Remove the two terminal block wire port access screws.
3. Connect output wires to processing equipment.
4. Group and place output wires in conduit. Position conduit at amplifier terminal block wire ports.
5. Connect conduit to control output signal wires ports.
6. Run output wires through wire ports, into amplifier terminal chamber.
7. Strip output wires back ¼ inch (6mm).
8. Connect output wires to terminals (see below).

NOTE: Use twisted pair shielded wire for all output wiring. Belden #1266A or equivalent.

Amplifier Output Wire Terminal Block Connections:

Reference Control Signal Wiring Diagrams on next two pages.



Terminal 1 +18V DC –

Function: 50mA max supply

Terminal 2 input 1 (+) – Input –

Functions: reset, positive zero return

Terminal 3 Output 1 (+) – Programmable Passive output to Badger® external counter

Functions: forward pulse, AMR pulse, flow set point, error alarm, empty pipe, flow direction
Active Output to external counter

Terminal 4 – Common field ground

Terminal 5 – Output 2 (+) – Programmable transistor

output – Passive output to Badger® external counter
Functions: reverse pulse, frequency output, preset output, flow set point, error alarm, flow direction
Active output to external counter

Terminal 6 – Ground from external counter device connected to terminal 5

Terminal 7 – RS485 A –

Terminal 8 – RS485 B –

Terminal 9 – Analog Output –

Terminal 10 – Common field ground

Terminal 11 – RS232 OUT –

Terminal 12 – RS232 IN –


Terminal 13 – Output 3 (+) Solid state relay output
Functions: preset output, flow set point, error alarm, empty pipe error, flow direction

Terminal 14 – Output 3 (-)

Terminal 15 – Output 4 (+) – Solid state relay output
Functions: preset output, flow set point, error alarm, empty pipe error, flow direction

Terminal 16 – Output 4 (-)

Auxiliary Input Wiring Diagram



Analog Output Wiring Diagrams

• Analog Output (Loop voltage = 18VDC Sourced, 750 Ω MAX) Function: 4-20mA, 0-20mA, 0-10mA



• Output 1
Transistor Output (open collector)
24VDC Max
.5W Max


Functions: Forward Pulse, AMR Pulse, Flow Set Point, Error Alarm, Empty Pipe, Flow Direction

Programmable

Passive Output Wiring



Active Output Wiring




• Output 2
Transistor Output (open collector)
24VDC Max
.5W Max


Functions: Reverse Pulse, Frequency Output, Preset Output, Flow Set Point, Error Alarm, Flow Direction

Programmable

Passive Output




Active Output




• Output 3
Solid State Relay Output
24V AC/DC Max
500mA Max

Functions: Preset Output, Flow Set Point, Error Alarm, Empty Pipe Error, Flow Direction



• Output 4
Solid State Relay Output
24V AC/DC Max
500mA Max

Functions: Preset Output, Flow Set Point, Error Alarm, Empty Pipe Error, Flow Direction



External Disconnect

CAUTION

Position this device in an accessible location.

Position and identify the disconnect device so as to provide safe and easy operation.

Label the disconnect device as being for the Mag Meter.

Install an external disconnect switch or circuit breaker that meets local standards.

AC/DC Power Wiring

For AC/DC power use three wire, sheathed, cable with cable diameter of 18 AWG (not supplied).

AC/DC wire insulation temperature class must not exceed the maximum ambient temperature of its location.

Use conduit and conduit fittings (not supplied) that are rated for Class I, Div 2 hazardous locations. To maintain a NEMA 4X rating, use watertight fittings that are rated NEMA 4X or better.


⚠ CAUTION

To prevent accidents connect main power only after all other wiring has been completed.


The amplifier is a microprocessor device. It is important that the power supply be as “clean” as possible. Avoid using power lines that feed heavy loads; pumps, motors, etc. If dedicated lines are not available, a filtering or isolation system may be required.

Power wiring is the same for meter mount and remote mount amplifiers.

1. Remove the Wire Port cover from amplifier connections chamber.
2. Lay out power cable and conduit to amplifier.
3. Place cable in conduit.
4. Strip cable back 2 inches (50mm).
5. Strip wires back ¼ inch (6mm).
6. Attach wires to amplifier
 - 6a. For AC wiring: terminal.



6b. For 24VDC wiring:



7. Connect conduit to amplifier.
8. Attach chamber cover.

Adjustable Display/Control Card

Because meter positioning sometimes places the amplifier display/programming chamber in an awkward position, the display/control card is adjustable in 90-degree increments.

⚠ WARNING

Disconnect main power to the unit before attempting any device maintenance.

To re-position or rotate the display/control card in the amplifier:

1. Remove display chamber cover. Turn the cover counterclockwise to remove it from the amplifier. If necessary, use a strap wrench.



2. Remove the 2 card screws and washers. (**NOTE:** Use a split screwdriver to prevent dropping screw into enclosure.)



3. Tilt card up/out approximately 45 degrees at the holding clips.



4. Gently pull card down and out from between holding clips.



5. Rotate card to appropriate position.

6. Angle card and position card holes between the holding clips.



7. Push card in, between holding clips. Lower card back into position and attach card with screws and washers.




8. Attach the chamber cover.



AMPLIFIER CONTROLS, CONTROL METHODS and DATA DISPLAY PROGRAMMING

The M-3000 amplifier display/programming chamber contains a display/control card. This card and its display screen provide easy access to meter information and the ability to view, program and adjust meter data parameters.



Card Display and Controls

The M-3000 uses a 2.5 X 1 inch (63 X 25mm) four line, 16-character, backlit, LCD display.



Display screens and screen data are manipulated with magnet switches or push buttons. By operating the switches or buttons different screens are accessed, program parameters are selected and changed and settings are reprogrammed.

If no contact is made with switches or buttons for 2 minutes, in any parameter, the display returns automatically to the Main Screen.

ACCESS to AMPIFIER SCREENS, DATA and PARAMETER PROGRAMMING

NOTE: The M-3000 can be programmed to meter many flow situations and serve a variety of purposes during a production process. To meet diverse needs there are a wide variety of programming options and parameters. Your metering requirements probably do not require the use of all program screens, options and parameters.

Your M-3000 amplifier is delivered preprogrammed, based on information available at the time the unit was ordered. In most instances it will not require any changes.

Use this section to program flow signal outputs or reprogram your meter to specific requirements.

Flow measurement and totalizing continues during amplifier programming.

Two Programming Methods

There are two methods for programming.

In one method a magnet wand is used to manipulate **+**, **-** and **E** switches to view and change screens and program functions and settings. The amplifier display chamber cover stays on.



The other method involves removing the display chamber cover and manipulating the **+**, **-** and **E** push buttons to view and change settings and program desired meter functions and settings.



AMPLIFIER SCREENS, MENUS and PROGRAMMING

Amplifier programming requires planning, moving and activating the **+**, **-** and **E** selections on three types of menu/parameter screens, List screen, Input Numbers screen and select ON or Off screen.

MAIN SCREEN(S)

The first screen is the Main Screen. It is always displayed when programming functions are not occurring.

NOTE: When programming, if no contact is made with switches or buttons for 2 minutes, in any parameter, the display returns automatically to your programmed Main Screen.

Two **Main Screen Format** settings are possible. Which setting to use is determined by the fluid Flow Direction through your meter. The settings are Uni-Directional flow or Bi-Directional flow (reference page 24, "Set FLOW Rate Unit of Measure and Set Totalizer Unit of Measure" to program flow units).


Both main screens display the rate of flow (R=) and flow units).

Uni-Directional Flow Main Screen

Uni-directional Flow totalizes pipe flow in only one direction, the flow direction arrow printed on the detector label. (reference page 25, "Set Flow Direction" to program for uni-directional mode)


Uni-directional readings, on the main display screen, are identified as R=, T1, T2 and PS.

R= Flow Rate



T1 registers Forward Volume

T2 registers Forward Volume and can be reset through Input 1.




PS registers Preset Batch Amount

With this information an operator can tell at a glance the volume going through the meter.

Bi-Directional Flow Main Screen

Bi-Directional Flow totalizes pipe flow in both directions (reference page 25, "Set Flow Direction" to program for Bi-Directional Mode)


Bi-directional totalizers readings, on the display screen, are identified as R=, T+, T-, TN and PS.



R= Flow Rate

T+ registers Forward Volume

T- registers Reverse Volume



TN Net Total = (T+) - (T-)

PS registers Present Batch Amount


With this information an operator can tell at a glance the volume going through the meter in both directions.

PASSWORD ENTRY

With your Main Screen showing on the display, switch or press **E**. Screen **PASSWORD??? 01** opens.

PASSWORD??? 01 is a typical Input Numbers screen.


If a password has been entered into your program, this screen opens (reference page 23, "Input a Password" for programming a password).




An underscore (**_**) is positioned under the first 0.

1. Switch or press **+** to increase the number by one digit. Switch or press **-** to decrease the number by one digit.
2. After the correct number is entered for that digit, press **E** to move the underscore to the next 0.
3. Repeat the number selection process for this and all the 0's.
4. After the last number is entered, press **E**.
5. The MAIN MENU appears.

However, if the wrong password was entered:
Screen **INVALID PSWD 02** opens.



1. Select **+**, **-** or **E** to return to the Main Screen.




2. Press **E** again.
3. The screen returns to **PASSWORD??? 01**. Enter the correct password as described above.


All passwords are factory set to 0000 (no password is programmed or required). If 0000 is the password, pressing **E** from the Main Screen opens the MAIN MENU screen.

Amplifier Access Switches/Buttons

Accessing amplifier menus, movement to and between screens, parameter selections and settings are all accomplished by pressing the **+**, **-** and **E** magnet operated switches or push buttons in conjunction with an on-screen location arrow.



Switch/Buttons (+ and -)



Select/Press **+** to:

- move text up by one line, relative to the on screen arrow, for each select/press when choosing menu or sub-menu list names
- move text up by one line, relative to the arrow, for each select/press when selecting a parameter setting from a list
- increase a number by one digit for each select/press when inputting parameter numeric settings

Select/Press **-** to:

- move text down by one line, relative to the on screen arrow, for each select/press when choosing menu or sub-menu list names
- move text down by one line, relative to the arrow, for each select/press when selecting a parameter setting from a list
- decrease a number by one digit for each select/press when inputting parameter numeric settings

E Switch/Button



Select/Press **E** to:

- To enter (open) a menu or sub-menu topic at which the arrow is pointing.
- Select between ON/OFF parameter settings for each select/press.
- Move the parameter numeric setting underscore (**_**) one place to the right for each select/press when inputting parameter numeric settings.
- SAVE a parameter numeric setting. After all numbers are input, press **E** and the setting is saved, the screen closes and the previous screen with the arrow pointing at "Exit this Menu" shows again. Select **E** again. That screen closes and the previous screen appears with the arrow pointing at its "Exit this Menu".

- Continue selecting **E** to return to the Main Screen.
- If your amplifier is not password protected, pressing **E** from the Main Screen accesses the MAIN MENU. The MAIN MENU is a list that provides access to all amplifier menus and parameters.
- If your amplifier is password protected and **E** is pressed from the Main Screen, the PASSWORD screen opens (reference PASSWORD??? 01, below).

How to Program

Amplifier screens, menus and program parameters are arranged in the familiar “branching” format where the MAIN MENU screen is a list of selections. The Main Menu list provides access to other lists, selections or parameter screens which provide input for meter programming.

The amplifier program uses three types of screens; a List screen, an Input Numbers screen and a select ON or Off screen.

```

MAIN MENU      00
-----
>Exit this Menu
Meter Setup
Measurements
Inputs/Outputs
Clear Totals
Communications
Info/Help
Logout
  
```

Sample List Screen

```

PULSES / UNIT 3D
Pulses / USG
→ 00000.100
Chg!+,- E=Next
  
```

Sample Input Numbers Screen

```

EMPTY CALIB. 1E
→Exit (NO save)
Volts = 0.00
Cal[OFF] E=ON
  
```

Sample Select ON or OFF Screen

The following pages introduce you to the screen formats, describe how to maneuver to and through them and provide some specifics about programming terminology and parameters.

If possible, have access to your amplifier display and controls and perform these screen manipulations.

MAIN MENU

The MAIN MENU contains a list of eight selections and an “Exit this Menu” choice. All amplifier programming and parameters are accessed from this list.

```

MAIN MENU      00
-----
>Exit this Menu
Meter Setup
Measurements
Inputs/Outputs
Clear Totals
Communications
Info/Help
Logout
  
```

Only four lines of text are visible on the display screen. Operating the **+** and **–** switches/buttons moves text up or down and into view.

When an item from the list on the MAIN MENU is selected, (press **E** when the item is in line with the arrow) either a screen opens that requires an action such as select a size or numeric unit for a parameter, turn a parameter on or off, etc. or a screen with another list may open requiring another selection be made to access and set a specific parameter size, numeric unit or on/off configuration.

Each screen has a name and number that displays at the top of the screen. Write down screen names, numbers and parameters that you access and change should other changes be needed later.

NOTE: Your metering requirements may not require the use of all screens, options and parameters.

MAIN MENU 00 is a typical List screen. It provides access to parameter screens.

The MAIN MENU is a list of eight selections and an “Exit this Menu” choice. All amplifier programming and parameters are accessed from this list.

1. Press **+** or **–** to position the arrow at a selection.

```


MAIN MENU      00
→Exit this Menu
Meter Setup
Measurements
  
```

2. For example, press **+** once to place the arrow at Meter Setup.

```

MAIN MENU      00
Exit this Menu
→Meter Setup
Measurements
  
```



3. Next, press **E**.




4. Screen METER SETUP 10 opens.

METER SETUP 10 is another List screen it provides access to common meter parameters.


1. Maneuver the **+** or **-** magnetic switches or push buttons to position the arrow at a selection.



2. For example, place the arrow at Pipe Dia. by pressing or activating **+** button once.



3. Press **E** to open the Pipe Dia. screen.



4. Screen Pipe Dia. 11 opens.


PIPE DIA. 11 is another List screen. It requires a parameter selection.

PIPE DIA. 11 is a list of pipe diameter sizes.

PIPE DIA.	11

Exit this Menu	
6mm	[1/4"]
8mm	[5/16"]
10mm	[3/8"]
15mm	[1/2"]
20mm	[3/4"]
25mm	[1 "]
32mm	[1 1/4"]
40mm	[1 1/2"]
50mm	[2"]
65mm	[2 1/2"]
80mm	[3"]
100mm	[4"]
125mm	[5"]
150mm	[6"]
200mm	[8"]
250mm	[10"]
300mm	[12"]
350mm	[14"]
400mm	[16"]
>450mm	[18"]
500mm	[20"]
550mm	[22"]
600mm	[24"]


5. Press **+** or **-** to position the arrow at the appropriate pipe size.



6. Press **E**.




7. A screen, with the statement [(xx mm [xx"])]
SELECTED appears for about 2 seconds.




It verifies that the selected pipe diameter size parameter was entered into the amplifier settings.

- The screen automatically returns to METER SETUP 10 with the arrow pointed at Exit this Menu.




Transitions


- Press + or – to position the arrow at another selection or E to return to the Main Menu.




- Use the E key to return to screen Main Menu 00.




- Next, press + three times to position arrow at Inputs/Outputs.




- Press E.




- Press + three times to position arrow at Digital Out. #1 on screen In/Outputs 30.




- Press E.



- Press + once to move the arrow across from Pulses / unit.




- Press or activate E.



Pulses / Unit 3D is a typical Input Numbers screen.


- When the screen opens, the arrow is pointing at a number.




- Use + or – selections to increase or decrease the underscored number to the desired digit.
- Select E to move the underscore to the next digit and repeat the number selection process.
- To skip a digit press E. The underscore moves to the next digit.
- When all digits are set, press E. Pulses / Unit 3D is programmed into the system and the screen Dig Output 1 33 returns.

Empty Pipe is a “branch” list screen from the MAIN MENU. From here calibrate ON or OFF is made.

- Press E to activate the Main Menu 00 screen.




- Press the + once to place the cursor at Meter Setup.



- Press E to bring up Meter Setup 10 screen.


- Press **+** five times to position the cursor at Empty Pipe.



```

METER SETUP 10
Calibration
→Empty Pipe
Chg. Password
  
```

- Select or press **E**.
- Screen Empty Pipe 15 opens.




```

EMPTY PIPE 15
→Exit this Menu
Cal. empty Pipe
Cal. full Pipe
  
```

Empty Pipe 15 is a typical select ON/OFF screen.

Empty Pipe is shipped **OFF**. To turn **Empty Pipe, On**:


- Press **+** once to move the cursor down one place, to **Cal. empty pipe**.
- Press **E**.



```

EMPTY PIPE 15
Exit this Menu
→Cal. empty Pipe
Cal. full Pipe
  
```

- In screen **EMPTY CALIB. 1E**, press **+** twice.
- Press **E** to turn **Cal=[ON]**.



```

EMPTY CALIB. 1E
Volts = 1.66
→Cal[ON] E=OFF
Exit WITH save
  
```

- Press **+** to move cursor to **Exit WITH save**.
- Press **E** to lock the selection into the program.

Continue pressing **E** to reverse through the screens to your **next programming selection** or to return to the **Main Screen**.

You have now used the **+**, **-** and **E** selections to access the three types programming screens, **List**, **Input Numbers** and **Select ON** or **Off** and maneuver through some meter programming.

What to Program

There are a variety of screens available. Refer to the "Flow Chart - Menu Structure" on page 35 for all programming options.


PROGRAMMING REQUIRED PARAMETERS

All meters have required parameters that must be programmed. They include a **Password** (if desired), the **Main Screen** for **Uni-or Bi-Directional Flow**, **Empty Pipe**, **Pulse Output** and **Analog Output**, among others.

This section presents keystroke details describing how to program required parameters.

Input a Password


- With Main Screen up, press **E**, to open MAIN MENU 00.



```

M-Series U1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
  
```


- With MAIN MENU 00 up, press **+** once to move cursor to Meter Setup. Press **E**.



```

MAIN MENU 00
Exit this Menu
→Meter Setup
Measurements
  
```


- On METER SETUP 10 screen, press **+** six times or **-** once to go to Chg. Password.



```

METER SETUP 10
Empty Pipe
→Chg. Password
  
```


- At CHG. PASSWORD 16 screen, input a password number.



```

CHG. PASSWORD 16
Enter new
→Password: 0000
Chg: +, - E=Next
  
```


- Or this screen comes up. Input the correct password.



```

PASSWORD??? 01
Please enter
→Password: 0000
Chg: +, - E=Next
  
```


- If the wrong number is input, INVALID PSWD comes up. Press **+**, **-** or **E** once.



```

INVALID PSWD 02
Wrong Password
Try again.
Any key exits
  
```

- Main Screen appears. Press **E** again.



```

M-Series U1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
  
```

8. PASSWORD??? 01 screen reactivates. Input the correct password.

```
PASSWORD??? 01
Please enter
→Password: 0000
Chg: +, - E=Next
```

Set Flow Rate: Unit of Measure and Totalizer - Unit of Measure

1. With Main Screen up, press **E**.

```
M-Series U1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
```

2. With MAIN MENU 00 active, press **+** twice (Measurements) and then **E**.

```
MAIN MENU 00
Meter Setup
→Measurements
Inputs/Outputs
```

3. On the MEASUREMENTS 20 screen press **+** once to place cursor at Flow Unit. Press **E**.

```
MEASUREMENTS 20
Exit this Menu
→Flow Unit
Totalizer Unit
```

4. From FLOW UNITS 21 press **+** or **-** to select a flow unit. Press **E**.

```
FLOW UNITS 21
OPM-Oz./min.
→GPM-Gal./min.
MGD-MegaGal/day
```

5. This **type** of screen shows for two seconds.

```
GPM-Gal./min.
** SELECTED **
```

6. The screen returns to MEASUREMENTS 20. With the cursor at Exit this Menu, press **+** twice to move cursor to Totalizer Unit. Press **E**.

```
MEASUREMENTS 20
Flow Unit
→Totalizer Unit
FullScaleFlow
```

7. From TotalizerUnit 22 press **+** or **-** to select a totalizer unit. Press **E**.

```
TotalizerUnit 22
Exit this Menu
→USG-US gallons
Cft-cu. feet
```

8. This type of screen shows for two seconds.

```
GPM-Gal./min.
** SELECTED **
```

9. Screen goes back to MEASUREMENTS 20.

```
MEASUREMENTS 20
→Exit this Menu
Flow Unit
Totalizer Unit
```

Set Full Scale Flow Rate Value

1. Press **+** three times to move the cursor to FullScaleFlow. Press **E**.

```
MEASUREMENTS 20
Totalizer Unit
→FullScaleFlow
LowFlowCutOff
```

2. At FullScale Flow 23 input the proper flow. Select **E** to move cursor as described earlier.

```
FullScaleFlow 23
Max=45189.1 GPM
→ 003000.000
Chg: +, - E=Next
```

3. Screen returns to MEASUREMENTS 20.

Set Low Flow Cutoff

1. Press **+** four times, to place cursor at LowFlow CutOff. Press **E**.


```
MEASUREMENTS 20
FullScaleFlow
→LowFlowCutOff
Flow Dir.
```

2. At LowFlowCutOff 24 screen input a percentage at the arrow. Press **E**.

```
LowFlowCutOff 24
% of 2999.99 GP
→ 000.20 %
Chg: +, - E=Next
```



Set Flow Direction

1. At MEASUREMENTS 20 press + five times to set the arrow at Flow Dir. Press E.




```
MEASUREMENTS 20
LowFlowCutOff
→Flow Dir.
Damping Factor
```

2. At FLOW DIR 25 press + or - to select Uni-Directional or Bi-Directional.



```
FLOW DIR. 25
Exit this Menu
→Uni-Directional
Bi-Directional
```


3. This type of screen shows for 2 seconds.



```
Uni-Directional
** SELECTED **
```


Set Damping Factor

1. At MEASUREMENTS 20 press + six times to move the arrow to Damping Factor. Press E.




```
MEASUREMENTS 20
Flow Dir.
→Damping Factor
-----
```

2. At DampingFactor 26 press Exit this Menu, No Damping or press a Time Frame.




```
DampingFactor 26
Exit this Menu
→No Damping
1 Second
```

3. If No Damping is selected, this **type** of screen shows for 2 seconds.




```
No Damping
** SELECTED **
```

4. And this **type** of screen shows for 2 seconds when Damping Factor time is selected.




```
5 Seconds
** SELECTED **
```

5. MEASUREMENTS 20 screen returns with the arrow pointing at Exit this Menu.




```
MEASUREMENTS 20
→Exit this Menu
Flow Unit
Totalizer Unit
```

6. Press E once to place cursor at Main Menu 00.



```
MAIN MENU 00
→Exit this Menu
Meter Setup
Measurements
```


7. Press E once to move cursor back to the Main Screen.



```
M-Series U1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
```


Empty Pipe Calibration

1. Press E once to move to Main Menu.




```
M-Series U1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
```

2. In the MAIN MENU 00, select Meter Setup.




```
MAIN MENU 00
Exit this Menu
→Meter Setup
Measurements
```

3. In METER SETUP 10, select Empty Pipe.



```
METER SETUP 10
Calibration
→Empty Pipe
Chg. Password
```

4. In EMPTY PIPE 15, select Cal. empty pipe. Next, press E.



```
EMPTY PIPE 15
Exit this Menu
→Cal. empty pipe
Cal. full pipe
```

5. Select Cal[OFF] E=ON, press or select E once to change OFF to ON. (**NOTE:** Make sure the Flow Detector Pipe is Empty.)

```
EMPTY CALIB. 1E
Volts = 3.30
→Cal[ON] E=OFF
Exit WITH save
```

NOTE: With the pipe empty the usage reading should be between 3.00 and 3.30 Volts.

6. Select Exit WITH save. Press **E** once to save the setting and return to EMPTY PIPE 15.

```
EMPTY CALIB. 1E
Cal[ON] E=OFF
→Exit WITH save
-----
```

7. In EMPTY PIPE 15, select Cal. full pipe. Then, press **E**.

```
EMPTY PIPE 15
Cal. empty pipe
→Cal. full pipe
Enable/Disable
```

9. Select Cal[OFF] E=ON, press or select E once to change to OFF to ON. (**NOTE:** Make sure the Flow Detector pipe is full of fluid.)

```
FULL PIPE CAL 1F
Exit (NO save)
→Volts = 2.49
Cal[OFF] E=ON
```

NOTE: The full pipe voltage reading should be below 3.00 Volts.

10. Press **+** once to move cursor to Exit WITH save. Press **E** once to save the setting and return to EMPTY PIPE 15.

```
FULL PIPE CAL 1F
Cal[ON] E=OFF
→Exit WITH save
-----
```

11. In EMPTY PIPE 15, press **+** three times to place cursor at Enable/Disable. Next, press **E**.

```
EMPTY PIPE 15
Cal. full pipe
→Enable/Disable
-----
```

12. In EMPTY CONTROL 1G, press **+** twice to move cursor to Det[OFF] E=ON. Press **E** once to switch OFF to ON.

```
EMPTY CONTROL 1G
Empty Pipe Det.
→Det[ON] E=OFF
Exit WITH save
```

13. Press **+** once to move cursor to Exit WITH save. Press **E** once to save the setting and return to EMPTY PIPE 15.

```
EMPTY CONTROL 1G
Det[ON] E=OFF
→Exit WITH save
-----
```

Pulse Output

1. Press **E** once to move cursor to Main Menu.

```
M-Series V1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
```

2. In the MAIN MENU 00, press **+** three times to move the cursor to Inputs/Outputs. Next, press **E**.

```
MAIN MENU 00
Measurements
→Inputs/Outputs
Clear Totals
```

3. At IN/OUTPUTS 30 press **+** three times to place the cursor at Digital Out. #1. Press **E**.

```
IN/OUTPUTS 30
Digital Input 1
→Digital Out. #1
Digital Out. #2
```

4. In DIG OUTPUT 1 33, press **+** once to move the cursor to Pulses / unit. Press **E**.


```
DIG OUTPUT 1 33
Exit this Menu
→Pulses / unit
Pulse width
```

You only need to do this if the function of output one (1) is to be Fwd Pulse or AMR (50ms pulse.) (Refer to page 36 - "Digital Out #1.")

5. In PULSES/UNIT 3D input a proper number as described earlier. Press **E**.


```
PULSES / UNIT 3D
Pulses / USG
→ 00000.100
Chg: +, - E=Next
```


6. The screen returns to DIG OUTPUT 1 33. Press or activate + twice, then press E.




This is only for Fwd Pulse. (Refer to page 36 - "Digital Out #1.")

7. Into screen PULSE WIDTH 3E enter a number. Press E.




8. The screen returns to DIG OUTPUT 1 33. Press + three times, then press E.

SET POINT




This is only for Flow Set Point. (Refer to page 36 - "Digital Out #1.")

1. Into screen SET PT. MIN 3F enter a number.




NOTE: When the flow rate falls below the minimum set point value (entered as a percentage of full scale,) the output activates.

2. The Screen returns to DIG OUTPUT 1 33. Press + four times, then press E.



3. In SET PT. MAX 3G enter a number.




NOTE: When the flow rate exceeds the set point max. value (entered as a percentage of full scale flow) the output activates.


This is only for Flow Set Point. (Refer to page 36 - "Digital Out #1.")

OUTPUT TYPE

1. Press or activate the letter E to return to screen DIG OUTPUT 1 33.




2. In DIG OUTPUT 1 33 press + five times, to Output Type.




3. In OUTPUT TYPE 3H press Normally Open or Normally Closed.


- Select N.O. or N.C. for any output. (Refer to page 36, "Digital Output #1.")




- Normally Opened or Closed ****Selected**** shows for two seconds.




- The screen goes back to DIG OUTPUT 1 33.




4. Press + six times, or - once to Select Function.




5. When Select Function is selected, screen Z1 appears for two seconds.



6. It then switches to SELECT OUT #1 3J. Make a selection. Press E.



7. This **type** of screen shows for two seconds and then returns to DIG OUTPUT 1 33.



Whichever selection is made from screen SELECT OUT #1 3J, the next screen always shows XXXXX ** SELECTED**.

The screen then returns to DIG OUTPUT 1 33 where you will have to:


1. Select Functions screen
2. Screen Z1 appears
3. Select another screen

Do this until all required Digital Outputs are programmed.


There are four Digital Outputs in this program. Perform the same for all of them, if applicable. (Note that not all output functions are available on all outputs.)

Analog Output


1. Press E once to move cursor to Main Menu.




2. In the MAIN MENU 00, press + three times to move the cursor to Inputs/Outputs. Next, press E.




3. At IN/OUTPUTS 30 press + once to place the cursor at Analog Output. Press E.




4. In ANALOG OUTPUT 31 press + once to move the cursor to Range Select. Press E.



5. In RANGE SELECT 3A select a range with the + button and then press E.




6. The screen returns to ANALOG OUTPUT 31. Press + twice to move the cursor to Zero Calibrate and then press E.





Connect amp meter to mA analog output pins 9 and 10.

7. In ANALOG ZERO 3B make a selection of Decrease or Increase based on what the amp meter is reading.



8. Press the E button until the amp meter reads the desired No Flow set point. (The line to the left of the selection rotates as the E button is pressed, to show that there is activity.)



9. Press **+** to set at Exit WITH save.


10. Press **E** to Save.

```
ANALOG ZERO 3B
Increase AO 1
→Exit WITH save
-----
```

11. After pressing **E**, the menu goes back to ANALOG OUTPUT 31. Press **+** three times to place arrow at FS Calibrate. Press **E** once.

```
ANALOG OUTPUT 31
Zero Calibrate
→FS Calibrate
-----
```

12. Screen ANALOG FS CAL 3C comes up. Press **+** to set the arrow across from Decrease AO or Increase AO. Press **E** button until amp meter reads the desired Full Scale Set-point.



13. Press **+** to set screen at Exit WITH save.

14. Press **E** to Save.

```
ANALOG FS CAL 3C
Decrease AO 1
→Increase AO 1
Exit WITH save
```

15. ANALOG OUTPUT 31 returns with the arrow pointing at Exit this Menu. Press **E**.

```
ANALOG OUTPUT 31
→Exit this Menu
Range Select
Zero Calibrate
```

16. IN/OUTPUTS 30 returns with the arrow pointing at Exit this Menu. Press **E**.

```
IN/OUTPUTS 30
→Exit this Menu
Analog Output
Digital Input 1
```


17. MAIN MENU 00 returns with the arrow pointing at Exit this Menu. Press **E**.

```
MAIN MENU 00
→Exit this Menu
Meter Setup
Measurements
```


18. The screen returns to the Main Screen.

```
M-Series V1.0
R= 0.0000 GPM
T1 0.000 USG
T2 -54.366 USG
```


The above programming sequence guided you through various screens and programming. These are the basic features that need to be programmed initially. Please refer to the programming flow chart located on pages 35-37 for all of the programming options.



M-3000 Meter Mount Amplifier on Detector



M-3000 Remote Mount Junction Box on Detector



Size		A		B		C		D		Est.Weight with Amplifier		Flow Range			
												GPM		LPM	
inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	Lbs	Kg	Min	Max	Min	Max
1/4	6	6.7	170	13.4	342	3.5	89	13.9	351	17	7.7	0.02	5	0.063	20
5/16	8	6.7	170	13.4	342	3.5	89	13.9	351	17	7.7	0.03	9	0.114	34
3/8	10	6.7	170	13.4	342	3.5	89	13.9	351	17	7.7	0.05	14	0.177	53
1/2	15	6.7	170	13.4	342	3.5	89	13.9	351	17	7.7	0.11	33	0.416	125
3/4	20	6.7	170	13.6	347	3.9	99	14	356	17	7.7	0.2	59	0.75	225
1	25	8.9	225	13.8	352	4.3	108	14.2	361	18	8.8	0.3	93	1.20	350
1 1/4	32	8.9	225	14.6	372	4.6	117	15	381	20.3	9.2	0.5	152	2.00	575
1 1/2	40	8.9	225	14.8	376	5.0	127	15.2	386	22	10	0.8	239	3.00	900
2	50	8.9	225	15.3	389	6.0	152	15.7	398	26	11.7	1	373	4.70	1400
2 1/2	65	11.0	280	16.5	420	7.0	178	16.9	429	35	15.7	2	631	8	2400
3	80	11.0	280	16.7	426	7.5	191	17.2	435	38	17.1	3	956	12	3600
4	100	11.0	280	17.8	452	9.0	229	18.2	461	49	22.1	5	1493	19	5600
5	125	15.8	400	19	484	10.0	254	19.4	493	60	27.1	8	2334	30	8800
6	150	15.6	400	20	510	11.0	279	20.4	519	71	32.1	11	3361	40	12700
8	200	15.8	400	21.9	558	13.5	343	22.9	583	95	43.1	20	5975	75	22600
10	250	19.7	500	26.2	677	16.0	406	26.6	676	130	59.1	30	9336	120	35300
12	300	19.7	500	28.3	720	19.0	483	28.7	729	219	99.3	45	13444	170	50800
14	350	19.7	500	30.2	768	21.0	533	30.7	779	287	130.2	60	18299	230	69200
16	400	23.6	590	33.1	842	23.5	597	33.5	851	354	160.9	80	23901	300	90400
18	450	23.6	590	34.4	876	25.0	635	34.9	885	409	185.3	100	30250	380	114000
20	500	23.6	590	33.7	855	27.5	699	38	964	502	228.3	125	37346	470	140000
22	550	23.6	590	39	991	29.5	749	39.4	1000	532	241.3	150	45188	570	170000
24	600	23.6	590	41.6	1057	32.0	813	42	1066	561	255.3	180	53778	680	200000

SPECIFICATIONS

Flow Range: 0.1 to 39.4 ft/s (0.03 – 12 m/s)

Flow Direction: Uni-directional or Bi-directional

Sizes: 1/4" to 24" (6 to 600mm)

Conductivity: Min. 5 micromhos/cm

Accuracy: $\pm 0.25\%$ of rate for velocities greater than 1.64 ft/s (0.50 m/s)

± 0.004 ft/s (± 0.001 m/s) for velocities less than

1.64 ft/s (0.50 m/s)

Electrode Materials: Alloy C, 316 stainless steel, gold/platinum plated, tantalum, platinum/rhodium

Liner Material: PFA from 1/4" to 3/8" (6 to 10mm), PTFE from 1/2" to 24" (15 to 600mm), soft and hard rubber from 1" to 24" (25 to 600mm), Halar® from 12" (300mm) to 24" (600mm)

Fluid Temperature:

With remote mounted amplifier

PFA, PTFE & Halar: -4°F to 248°F (-20°C to 120°C) @ Max. ambient temp. of 122°F (50°C)

Soft & Hard rubber: 32°F to 178°F (0°C to 80°C) @ Max. ambient temp. of 122°F (50°C)

With meter mounted amplifier

PFA, PTFE, & Halar: -4°F to 212°F (-20°C to 100°C) @ Max. ambient temp. of 122°F (50°C)

Soft & hard rubber: 32°F to 178°F (0°C to 80°C) @ Max. ambient temp. of 122°F (50°C)

Coil Power: Pulsed DC

Pipe Spool Material: 316 stainless steel

Spool Housing Material: Carbon steel, welded - NEMA 4X/6P (IP66/IP67). Tested at 1.8m (6 feet) for 24 hours.

Junction Enclosure Material: (for remote mounted amplifier option) Cast Aluminum (powder coated paint), NEMA 4X/6P (IP66/IP67). Tested at 1.8m (6 feet) for 24 hours.

Flanges: Carbon Steel or 316 stainless steel (ANSI B16.5 Class 150 RF)

Grounding Rings (optional, 2 required): 316 stainless steel or Alloy C

Meter Size **Thickness (one ring)**

1/4" to 10" (6 to 250mm)

.135" (3.43mm)

10" to 24" (250 to 600mm)

.187" (4.75mm)

Grounding Electrode (optional): Alloy C, 316 stainless steel, gold/platinum plated, tantalum, or platinum/rhodium

Electrical Classification: FM approved for Class I, Div 2 Groups A-D,

Class II, Div 2 Groups F&G - CSA Certified



Pressure Limits: Max. 150 psi (10 bar)

Ambient Temperature: -4°F to 122°F (-20°C to 50°C)

Locations: Indoor and outdoor

Altitude: Maximum 6500 feet (2000m)

AMPLIFIER SPECIFICATIONS



SPECIFICATIONS

Power Supply: AC or optional 24VDC

AC Power Supply - 85-265VAC 45-65Hz

Voltage Fluctuation = $\pm 10\%$ of nominal

Over Voltage = Category II

Power Consumption = 20W

DC Power Supply - (optional) + 24VDC $\pm 10\%$ 8W

Accuracy: $\pm 0.25\%$ of rate for velocities greater than 1.64 ft/s (0.50 m/s)

± 0.004 ft/s (± 0.001 m/s) for velocities less than 1.64 ft/s (0.50 m/s)

Repeatability: 0.1% of rate

Flow Range: 0.10 to 39.4 ft/s (0.03 to 12 m/s)

Fluid Conductivity: Min. 5.0 micromhos/cm

Flow Direction: Unidirectional or bidirectional (programmable)

Totalization: 3 separate displayable totalizers – 10 digits (programmable - forward, reverse and net)

Analog Outputs: 0-10mA, 0-20mA, 4-20mA

(programmable and scalable). Voltage sourced (18VDC) – isolated. Max. loop resistance = 750 Ω

Frequency Output: Open Collector – Max. full scale flow = 10KHz

Digital Outputs:

(2) Open collector, (programmable – scaled pulse, flow alarm, status, or frequency output) Max. 24VDC, 0.5W

(2) AC solid state relay (programmable – flow alarm or status). Max. 24VDC@0.5A

Communication: RS232C serial, standard ANSI terminal compatible data stream

Pulse Width: Open Collector, 5ms to 1 second

(programmable) or automatic 50% duty cycle (PW=0)

Min-Max Flow Alarm: Open collector or solid state relay (programmable – 0 to 100% of flow)

Empty Pipe Detection: Field tunable for optimum performance based on specific application

Excitation Frequency: Programmable - 3.75Hz, 7.5Hz or 15Hz (3.125, 6.25, 12.5)

Auxiliary Input: Max. 24VDC (programmable – positive zero return, external totalizer reset or preset batch start)

Noise Dampening: 1 to 30 seconds (programmable)

Units of Measure: U.S. gallons, imperial gallons, million gallons per day, cubic feet, cubic meters, liters, oil barrels, pounds, ounces, acre feet

Low Flow Cut-Off: 0 to 100% of full scale (programmable)

Zero-Point Stability: Automatic correction

LC Display: 4 lines X 16 character alphanumeric – back light, actively displays 3 totalizer values, flow rate, alarm status, output status, error / diagnostic messages

Programming: Internal 3 button or external magnetic wand

Galvanic Separation: 500 volts

Electrical Classification:

FM approved for Class I, Div 2, Groups A-D

Class II, Div 2, Groups F and G - CSA Certified

Housing: Amplifier enclosure and remote junction enclosure: cast aluminum (powder coated paint)

Housing Rating: Amplifier enclosure and remote junction enclosure – NEMA 4X/6P (IP66/IP67)

Mounting: Direct detector mount or remote wall mount – bracket included. (for remote mount, max. cable distance = 100 ft (30M))

Field Wiring Entry Ports: (3) $\frac{1}{2}$ " NPT, internal thread

Ambient Temperature: -4°F to 122°F (-20°C to 50°C)

Relative Humidity: Up to 90% non-condensing

Locations: Indoor and outdoor

Altitude: Maximum 6500 feet (2000m)

MAINTENANCE

Mandatory, routine or scheduled maintenance should not be required for the Badger® M-3000 Mag Meter electronics or flow tube after proper installation.

However, some occurrences may require personnel to perform the following:

- Flow Tube and Electrode Cleaning
- Fuse Replacement
- Amplifier I&C Card Stack Replacement

These maintenance procedures are discussed in this section.

⚠ WARNING

Disconnect main power to the unit before attempting any device maintenance or cleaning.

Do not clean components inside the amplifier or junction box.

Flow Tube and Electrode Cleaning

At times flow tube, electrodes, amplifier/junction box housings and the amplifier window may need periodic cleaning, depending on process fluid properties, fluid flow rate and surrounding environment.



Clean the flow tube and electrodes by following the material handling and cleaning procedures documented in MSD Sheets for the product(s) that were in contact with the flow tube and electrodes.

Should flow tube and/or electrode cleaning become necessary:

1. Disconnect detector from pipeline.
2. Clean electrodes with isopropyl alcohol or fresh, clean water depending on the chemical compatibility of the measured fluid.
3. Reconnect detector to pipeline

Fuse Replacement

⚠ WARNING

Disconnect main power to the unit before attempting any device maintenance.

⚠ CAUTION

Risk of electrical shock. Replace fuse ONLY with the same type and rating.

Authorized personnel must perform fuse replacements.

Replace fuses with fuses of the same ampere rating and type. Refer to wiring diagrams when ampere ratings are unknown or questionable.

Detector coil and incoming amplifier power supplies are each protected by a fuse in the amplifier.

Detector coils are protected by a 630mA, 250VAC, slow blow fuse, part number 65621-001.

For the AC powered version, the incoming amplifier power is protected by a 500mA, 250VAC, slow blow fuse, part number 65621-002.

For the 24VDC powered version, the incoming amplifier power is protected by a 630mA 250VAC, slow blow fuse, part number 65621-001.

Fuse ratings are listed on the circuit board, next to the fuse holders. Refer to the M-Series™, Model M-3000 Repair Parts List (IRP-210-01).

To access and replace fuses:

1. Remove display chamber cover. Turn the cover counterclockwise to remove it from the amplifier. If necessary, use a strap wrench.




2. Remove the 2 display card screws and washers.




3. Tilt card up/out approximately 45 degrees at the holding clips.



- Fuses are in the round/black fuse holders. Use a flat screwdriver to turn the holder cap counterclockwise until the lock tab reaches the opening and the holder and fuse disengage.



- Replace the fuse.



- Reverse steps 1 to 3 to assemble the unit.


Amplifier Printed Circuit Board (PCB) Stack Replacement

All M-3000 mag meters operate through printed circuit boards (PCBs) housed in the amplifier. The PCBs are grouped in a stack located behind the display/control card in the display/programming chamber.

Because PCBs are complex circuits, with all meter functions enabled through multiple links and layers, determining the exact board and circuit that is causing a system problem is difficult and usually requires test equipment.

Should a meter problem occur:

- Call Badger Meter at (877) 243-1010, and discuss the problem with a Technical Support Specialist.
- If the problem appears to originate in a PCB, it will be recommended that the entire PCB stack be removed and returned to Badger Meter.



PCB Stack in Amplifier

REMOVE PCB STACK

⚠ WARNING

Disconnect main power to the unit before attempting any device maintenance.

- Remove display/programming chamber cover. Turn the cover counterclockwise to remove it from the amplifier. If necessary, use a strap wrench.




- Remove 2 display card screws and washers. Place in storage for reuse.






- Tilt display card up/out approximately 45 degrees at the holding clips.




- Gently pull card down and out from between holding clips.
- Disconnect display card plug from left side of PCB display.




6. Disconnect the Power, Coil, Electrode and I-O plugs and harnesses from the PCB interconnect card.



7. Remove the 4 screws holding the PCB stack in the amplifier housing. Place in storage for reuse.




8. Gently remove the card stack from the amplifier housing. Do not tug or pull to remove the stack. Ease it out carefully.




9. Carefully wrap and package the PCB stack and display card. Send back to Badger Meter.
10. Reverse these steps to install a PCB stack.

When replacing the PCB stack:

- a.) Be sure to place the two lower feet of the circuit board support along the edges of the amplifier housing.
- b.) Gently move the stack back into the housing until the top holes at the top mate with the housing. (The stack is not connected to the circuit board in this picture.)



11. When placing display card back into PCB Display, verify mark and red stripe are aligned with Number 1.



FLOW CHART - MENU STRUCTURE


In the Flow Chart:

1. Each separate screen is inside a box.
2. If a screen “branches”, an arrow points right and each screen of the branch is in a box.
3. When there is text, but it's not in a box, that signifies a parameter setting and a short explanation is given of the parameter.

Mark on the chart what parameters need to be set. Note parameter settings on the chart. Program your amplifier accordingly.

Keep the chart as a reference for other shifts and personnel and to monitor meter performance.

Menu Structure



Digital Input 1

Select function for input.

Digital Out. #1

Open collector

Transistor

Pulses / unit
Pulse width
Set point min.
Set point max.
Output Type
Select Function

Set for Forward pulse output
Set for Forward pulse output
Set for Flow Set Point output
Set for Flow Set Point output
Select N.O. or N.C. for any output function.

None

Fwd Pulse / AMR

Forward flow pulse output.

AMR

Forward flow pulse for AMR devices.

Flow Set Point

Output will open or close based on set points.

Error Alarm

Output will open or close during error conditions.

EmptyPipe Error

Output will open or close when the pipe is empty.

Flow Direction

Output will open or close when flow direction changes.

Digital Out. #2

Open collector

Transistor

Pulses / unit
Pulse width
Full Scale Freq
Preset Amount
Set point min.
Set point max.
Output Type
Select Function

Set for Reverse pulse output.

Set for Reverse pulse output.

Set for Frequency output. Full scale = ? Hz

Set batch amount for Preset Output.

Set for Flow Set Point output

Set for Flow Set Point output

Select N.O. or N.C. for any output function.

None

Reverse Pulse

Reverse flow pulse output.

Freq. Output

Frequency out is proportional to rate of flow.

Preset Output

Output will open or close when preset amount is reached.

Flow Set Point

Output will open or close based on set points.

Error Alarm

Output will open or close during error conditions.

EmptyPipe Error

Output will open or close when the pipe is empty.

Flow Direction

Output will open or close when flow direction changes.

Digital Out. #3

Solid state relay

Preset Amount
Set point min.
Set point max.
Output Type
Select Function

Set batch amount for Preset Output.

Set for Flow Set Point output

Set for Flow Set Point output

Select N.O. or N.C. for any output function.

None

Preset Output

Output will open or close when preset amount is reached.

Flow Set Point

Output will open or close based on set points.

Error Alarm


Output will open or close during error conditions.

EmptyPipe Error

Output will open or close when the pipe is empty.

Flow Direction

Output will open or close when flow direction changes.



Please call Badger Meter's Technical Support department at (877) 243-1010 for questions related to programming and set-up.

M-Series™ is a trademark of Badger Meter, Inc.
Badger® is a registered trademark of Badger Meter, Inc.
Halar® is a registered trademark of Ausimont U.S.A., Inc.



Please see our website at
www.badgermeter.com
for specific contacts.

Copyright © Badger Meter, Inc. 2009. All rights reserved.

Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists.



BadgerMeter, Inc.

P.O. Box 245036, Milwaukee, WI 53224-9536

Telephone: (414) 355-0400 / (800) 456-5023

Fax: (414) 355-7499 / (866) 613-9305

www.badgermeter.com