



***IMPORTANT !!!! Read this manual before
attempting any installation, wiring or operation.***



SCOPE OF THE MANUAL

This manual contains information concerning the installation, operation and maintenance of Badger magnetic drive turbo meters. To ensure efficient operation of the meters, the instructions given in this manual should be thoroughly read and understood. Retain the manual in a location where it is readily available for reference.

Maximum Operating Temperature	250½ F (120½C)
Maximum Operating Pressure	150 PSI (10 Bar) (Optional 300 PSI (Bronze), 250 PSI (Cast Iron)
Accuracy Over Entire Range*	± 1.5%
Repeatability	0.5 or Better
Connections	Round Flange ASA or DIN
Body Materials	SS 316, Bronze, Cast Iron
Rotor and Nose Cone Materials	Ryton
Head Assembly Materials	SS 316 or Bronze
Straightening Vane Material	SS 316
Head Gasket Materials	Asbestos, Nitrile or Chloroprene
"O" Ring Materials	EPR, Buna, Viton A
Bearing and Magnet Material	Ceramic
Spindle	SS 316

INSTALLATION

UNPACKING AND INSPECTION

To avoid damage in transit, Badger turbo meters are shipped to the customer in special shipping containers. Upon receipt of the order, perform the following unpacking and inspection procedures:

NOTE: If damage to a shipping container is evident upon receipt of a meter, request the carrier to be present when the meter is unpacked.

Retain the container and all packing material for possible use in reshipment or storage. Visually inspect the meter and applicable accessory device for any physical damage. If damage is found, notify carrier for insurance purposes.

INSTALLATION

The procedures for installing Badger turbo meters are essentially the same for all meter sizes. Any special instructions required for the installation and/or electrical connection of meter-mounted or free-standing accessory devices such as registers, pulse transmitters, valves and remote batch controllers will be provided as a supplement to this manual.

a. PRELIMINARY CONSIDERATIONS

1. Badger's 2" through 6" industrial turbo meters are designed for operation in HORIZONTAL piping arrangements. However, some applications will allow vertical mounting; please contact the factory for review.

2. If solid material is present in the liquid to be metered, a strainer may be required in the facility piping upstream of the meter. The 2", 3" and 4" meters require a strainer with 1/16" diameter holes and the 6" meter requires a strainer with 1/8" diameter holes.

3. To permit periodic cleanout of the meter and to provide a convenient means of stopping fluid flow during maintenance, it is recommended that a flushing system be incorporated into the facility piping arrangement.

b. INSTALLING THE METER

1. Install the meter in the pipeline making sure that the flow arrow on the meter housing is in proper relation to the direction of liquid flow. It is also recommended that (10) pipe diameters upstream and (5) pipe diameters downstream of straight pipe be incorporated with no obstructions. If this is not possible, please contact factory to review acceptability of installation.

2. Install and tighten the flange connection bolts.


3. To relieve possible strain on the piping due to the weight of 4" and 6" turbo meters, it is recommended that consideration be given to installation of a meter support under the meter housing.

PERFORMANCE

Complete the following checks to ensure that the meter is properly installed and operational.

a. Slowly open the upstream valve to apply liquid pressure to the meter and check the flange connections for possible leaks. Retighten the flange bolts as required.

b. Perform a functional test of the turbo meter using the adjustment and calibration procedure in this manual.



OPERATION

GENERAL OPERATING INSTRUCTIONS

CAUTION: Regardless of the operating procedure used, the valves or devices controlling the flow of liquid through the turbo meter must always be opened and closed slowly or in stages to prevent shock loads that may damage the meter's rotor assembly.

a. MANUAL OPERATION

These procedures are intended for use in simple metering applications where the flow of liquid through the meter is controlled by hand-operated valves located in the facility piping upstream and downstream of the meter.

1. Slowly open the upstream valve; apply liquid to meter.
2. Slowly open the downstream valve to initiate metering.
3. Adjust the downstream valve so that the rate of flow does not exceed the maximum continuous flow rate specification of the meter.
4. To stop metering, slowly close the downstream valve, then close the upstream valve.

b. ACCESSORY CONTROLLED OPERATION

The step-by-step operating procedures used in accessory controlled metering applications are dependent on the specific function of the meter-accessory employed and its electrical or pneumatic interconnection with the flow control device or devices. Refer to the IOM manuals covering the applicable accessories for specific operating instructions.

SHUTDOWN INSTRUCTIONS

If the turbo meter is to be shutdown for an extended period of time, it is recommended that the measuring chamber be thoroughly flushed to prevent the settling out of undissolved solids or the accumulation of corrosive deposits.

MAINTENANCE

MAINTENANCE EQUIPMENT

With the exception of a special change gear mesh gage and a calibration test tank, the tools required are the usual compliment of standard hand tools used by plumbers and mechanics.

Truarc Right-Angle Pliers Truarc P/N 1549
(Badger P/N 57321-1)

Change Gear Mesh Gage Badger P/N 21747

PREVENTIVE MAINTENANCE

a. PERIODIC INSPECTION

1. Visually inspect the turbo meter and meter-mounted accessory. Repair or replace components as required based on the visual inspection.
2. Verify that the meter operates at the proper flow rate and pressure. A loss in pressure, coupled with the resulting decrease in flow rate, may indicate the screen in the upstream pipeline is clogged with material and requires cleaning.

b. CLEANING

1. Clean all dust, dirt, grease, moisture or other foreign material from the exterior of the meter and meter-mounted accessory.
2. If the piping arrangement of the facility includes a flushing system, shutoff the liquid flow to the meter. Flush the interior of the meter with an appropriate cleaning fluid to remove any buildup of deposits or corrosion on the internal portion of the meter.

CALIBRATION CHECK AND ADJUSTMENT

Accuracy of Badger turbo meters is tested at the factory with water. However, due to possible use of liquids that could vary in viscosity, it may be necessary to recalibrate a meter under operating conditions. The following instructions are to assist in performing a calibration adjustment.

a. ACCURACY TEST

1. Place a test tank of known volume at output of meter.
2. Operate the meter until the test tank is filled to a calibrated level. Run at the actual flow rate used in the operation.
3. Record the quantity indicated on the meter accessory.
4. Perform the following calculations to determine percent of accuracy of the meter-accessory combination:

$$\frac{\text{Qty. Indicated on Accessory}}{\text{Actual Quantity in Test Tank}} \times 100 = \text{Meter Accuracy}$$

EXAMPLE 1:

$$\frac{95 \text{ Gallons}}{100 \text{ Gallons}} \times 100 = 95\% \text{ Accuracy}$$

In this example, the accessory is slow and must be speeded up by a change gear or electronic scaling correction.

EXAMPLE 2:

$$\frac{104 \text{ Gallons}}{100 \text{ Gallons}} \times 100 = 104\% \text{ Accuracy}$$

In this example, the accessory is fast and must be slowed down.

b. CHANGE GEAR CORRECTIONS

If the test indicates that an adjustment is required, proceed as follows:

1. Remove the change gears from the spindles by loosening the setscrew. NOTE: Both the O.D. dimension (in decimal inches) and the number of teeth are stamped on each gear.
2. Calculate the ratio of existing change gears as follows:

$$\text{Ratio} = \frac{\text{No. of Teeth on Register Change Gear}}{\text{No. of Teeth on Meter Register Base}}$$

3. Calculate the new change gear ratio required by multiplying the ratio of existing change gears by percent-of-meter accuracy determined in test.

EXAMPLE:

$$\text{Existing Change Gear Ratio} = \frac{42 \text{ Teeth}}{43 \text{ Teeth}} = .976$$


$$\text{Meter Accuracy} = 95\%$$

$$\text{Corrected Change Gear Ratio} = .976 \times \frac{95}{100} = .927$$

4. Select a combination of new change gears that match the corrected change gear ratio. If stocked change gears are not available, submit order for change gears to your nearest Badger Meter representative or the Industrial Division of Badger Meter Inc.

NOTE: When ordering, give the serial number of the turbo meter which is stamped on the outlet flange of the meter. Specify the meter size and accessory employed along with the number of teeth and diameter on existing change gears. Specify the corrected change gear ratio.

5. Install the corrected change gears, taking care that the correct change gears are assembled to the appropriate spindles (see example in figure below). For registers, refer to Servicing section for instructions covering the proper method of installing and meshing change gears. On meters with 76 Series registers, provision for change gear adjustment is built in. See the applicable register IOM manual for recalibrating instructions.




Change Gear Location
Register Base and Register Assembly

c. ELECTRONIC SCALING CORRECTION.

If the test results indicates an adjustment is required, see the instruction manual for that accessory for procedure to change scale factor.

CALIBRATING 2" AND 3" METERS

Badger's 2" and 3" turbo meters with bronze and cast iron housings and bronze heads are equipped with a bypass valve for "minor" calibration adjustment in the field. Test the meter's accuracy to determine if recalibration is required. If the meter is out of calibration, proceed as follows:



Calibrating 2" and 3" Turbo Meters

1. Remove the bypass cover nut with a wrench.
2. Using a wide-bladed screwdriver, loosen the bypass valve lock ring.
3. Adjust the bypass valve with a screw drive in the following manner (see page 5):

a. To INCREASE registration, turn the slot in the valve perpendicular to the axis of the meter (line of flow). This will restrict the amount of volume flowing through the bypass and increase flow through the metering chamber.

b. To DECREASE registration, turn the slot in the valve parallel to the axis of the meter. This will increase liquid volume through the bypass and decrease flow through the metering chamber.


NOTE: The total range of the bypass adjustment occurs within a 90 degree or quarter turn of the valve from the parallel, inline position to the perpendicular position, or vice versa. The total range of adjustment is about four percent. Tested and calibrated at the factory, the bypass valve will be set at about 45° from the full "open" or "closed" position. This setting will allow for a $\pm 2\%$ adjustment to recalibrate the meter in the field.

4. With the valve turned to the desired bypass setting, tighten the valve lock ring.
5. Install and tighten the bypass valve cover nut.
6. Retest the meter to confirm the accuracy of the bypass adjustment. If the meter is still out of calibration, repeat the procedure outlined above.

REGISTER BASE REPLACEMENT

Badger turbo meters can be serviced without removing the meters from the system. To inspect or replace component parts of the head assembly, close the upstream and downstream valves. If the installation is equipped with an inlet and drain valve for flushing the meter, open the drain valve to relieve pressure from within the meter. However, if the meter piping is not equipped with a drain valve, proceed as follows to relieve pressure within the meter:

1. Do not remove the register base from the operating head assembly. The entire head assembly must be removed as a complete unit (See figure below).
2. Loosen each of the head bolts about one and one-half turns. Do not remove the bolts completely.
3. If the gasket-seal between the meter head and the housing is not leaking at this time, pry the head assembly loose with a screwdriver. To accomplish this, insert the screwdriver from the outlet side of the head assembly where the head and housing join together.



Turbo Meters Serviced Without Removal from the Line

CAUTION: Exercise precaution to make certain that fluid does not spray from the meter. The liquid spray could contact electrical equipment and create an electrical hazard.

4. Allow the meter to drain and relieve internal pressure.

5. When pressure is relieved, remove the head bolts and shift the head assembly toward the outlet-end of the meter to release the head-to-housing seal. Then lift the entire head assembly from the housing and, at the same time, tilt the operating head up to prevent the rotor from falling off the rotor spindle.

NOTE: Rotors are furnished with two-pole or four-pole magnets depending on the type of accessory.

6. When the operating head has been removed, lift the rotor out of the rotor cage and set it aside. Remove the head gasket.

NOTE: A dummy cover plate is available to close the meter in the line and continue service while the operating head assembly is being inspected or parts are being replaced.

7. To remove the register base from the head assembly, loosen the seal screw on the base with a screwdriver. Rotate the base 45 degrees in either direction to release it from the bayonet lock detents on the head assembly.

8. The register base retaining ring is accessible through the rotor cage in the head assembly. With a Truarc right-angle pliers #1549, expand and remove the register retaining ring on the extension tube. When this is accomplished, the register base can be removed from the head assembly.

9. To reinstall or replace the register base, repeat the procedure above in reverse making sure that the retaining ring has been reinstalled on the extension tube.

NOTE: The head unit has a gasket bonded to the periphery of the rotor cage. Depending on the chemical solution to be metered, the gasket will be made of EPR, Buna N or Viton A material. Re-inserting the head assembly into the meter housing correctly will require compressing the gasket slightly. This is done by tilting the top of the register base on the head toward the inlet side of the meter. The meter head has a pilot diameter machined into the cage at the gasket face. This pilot diameter must extend through the housing gasket inner diameter and into the housing bore. After lowering the head assembly into the housing, move the entire head assembly straight toward the inlet side of the meter. The pilot diameter must snap into the bore of the housing to provide a tight seal.

10. With the head gasket aligned and the head assembly properly positioned in the housing, reinstall and tighten the head bolts (between 90-180 in.-lbs. of torque).

11. Close the flushing system drain valve. Open the upstream valve partially, then open the downstream valve slightly which will purge any air from the service line. Then open both valves completely.


SERVICING

Refer to the following paragraphs for instructions covering the removal, inspection and installation of service parts and assemblies. Any service or repair procedures that apply to a meter-mounted or free-standing accessory are provided in the IOM instruction manual pertaining to that device (also provided as a supplement to this manual.) If satisfactory repair cannot be made, contact the Industrial Division of Badger Meter, Inc.

a. CHANGE GEAR REPLACEMENT

1. Replacing the change gear on the register base spindle requires no gage to properly mesh this gear with the register change gear. A shoulder-stop is built into the spindle at the proper gear height thus eliminating gear adjustment.

2. The change gear in the register should be installed with the aid of a Badger change gear mesh gage (P/N 21747) to ensure proper gear mesh. The procedure is as follows:



Replacing Turbo Meter Change Gears

a. Place the bottom of the register on the top edge of the gage (see Figure - page 6).

b. Adjust the change gear on the register spindle so that it rests against the "top" of the slot in the gage. Holding the change gear in this position, tighten the setscrew in the hub of the change gear.

NOTE: Install the change gears on the spindles with the hub of the gears in the "UP position.

c. Carefully install the register on the base making sure that the gears fully mesh. Install and tighten the register seal screws.


CAUTION: Take care not to bend the spindles when installing the gears or reassembling the register to the register base.

INSTRUCTIONS FOR REMOVING THE GEAR TRAIN ASSEMBLY WITH MAGNET

The gear train assembly can be removed and replaced without removing the turbo meter from the line.

Two gear train assemblies are used with industrial turbo meters. To find out what the gear train ratio is, count the number of spindles (gear and pinions) that protrude through the five mounting holes provided in the top plate of the gear train assembly. If there are only three spindles, the gear ratio is 366:1 and if there are five spindles, the gear ratio is 1200:1.

1. Remove the register, transmitter or adapter mounted on the register base.



Release the retainer ring from the groove to free the gear train assembly from the base


2. Use a small screwdriver to release the retainer ring from the groove in the wall adjacent to the top plate of the gear train assembly.

3. Grip the change gear spindle and lift to remove the gear train assembly with magnet from the register base.

4. Remove the accessory change gear or coupling from the gear train spindle. Before removing, note the location of the change gear (or coupling) on the spindle so that it can be reinstalled in the same location.

NOTE: A flat surface is provided at the top of the spindle of the change gear assembly so that the setscrew in the change gear or coupling can be properly seated and tightened to the spindle.


5. Gear train assemblies are packaged with the magnet and spindle assembly disassembled from the gear train assembly. Before assembling, carefully check the spindle for minute burrs on the threaded end of the spindle. If there are burrs, use a crocus cloth and carefully remove them from the spindle. This will prevent damage to the surface of the jewel bearing when inserting the magnet spindle through the jewel-bushing in the bottom plate of the gear train assembly. An "E" ring should be mounted on the spindle. If missing, remove the "E" ring from the replacement spindle and snap it into the grooved collar near the threaded end of the spindle.



Installing the magnet spindle assembly to the gear train assembly

ITEM NO.	PARTS DESCRIPTION
1	Hood , Register, 258
2	Gasket , Register Hood
3	Screw , Register Cover, 258
4	Screw , Register Cover, 258
5	Lock Washer , Register, 258
6	Change Gear , Accessory (Note 5)
7	Change Gear , Adapter (Note 5)
8	Setscrew , Change Gear
9	Tetraseal , Base Assembly
10	Register Base Assy. (Note 4)
11	Register Base Only
12	Gear Train, Base Assy. (Note 4)
13	Retaining Ring , Base Assy.
14	Retaining Ring , Register Base
15	Spacer , Register Base
16	Tetraseal , Meter Head Adapter
17	Bolt, Hex. , Meter Head
18	Meter Head, Machined (Notes 2 & 6)
19	Nut, Hex. , Rotor Spindle
20	Lock Washer , Rotor Spindle
21	Rotor & Spindle Assy. (Note 3)
22	Tetraseal , Meter Head (Note 1)
23	Nose Cone (Note 2)
24	Gasket , Head Assy. (Note 2)
25	Housing (Note 1)
26	Retaining Ring , Straightening Vane
27	Straightening Vane Assy. , For Bronze, Cast Steel, Stainless Steel Meters
28	Straightening Vane Assy. (For Cast Iron Meter Only)
29	Straightening Vane (2" Only)
30	Straightening Vane (2" Only)
31	Straightening Vane (2" Only)
32	Nut , Bypass Cover
33	"O" Ring , Bypass (Note 2)
34	Lock Ring , Bypass
35	Bypass
36	Meter Head Assy. , Complete (Notes 2 & 6)

ILLUSTRATED PARTS LIST



NOTE 1 Advise body material, flange rating (150 psi or 300 psi).

NOTE 2 Material will depend on corrosiveness of fluid being metered.

NOTE 3 Number of poles in magnet will depend on type of meter accessory.

NOTE 4 Gear train ratio is marked on plate of adapter (i.e., 1200:1 or 366:1).

NOTE 5 Number of teeth and gear diameter is stamped on each gear.

NOTE 6 Advise size of meter.

NOTE 7 Advise units of measure (i.e., gallons, m3, etc.)



Please see our website at
www.badgermeter.com
 for specific regions and contacts.

Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding bid obligation exists.



BadgerMeter, Inc.

P.O. Box 245036, Milwaukee, WI 53224-9536
 Telephone: (414) 355-0400 / (877) 243-1010
 Fax: (414) 355-7499 / (866) 613-9305
www.badgermeter.com