
MSE-1 & PC-100 CONTROLLER

WIRING DIAGRAM

APPLICATION BRIEF



NOTES

1. Refer to page 6 of IOM-036 for connections to K1.
2. Use shielded cable for transmitter connections. Connect shield to terminal 32 only.

BadgerMeter,Inc.
P. O. Box 245036 Milwaukee, WI 53224-9536
Telephone: (414) 355-0400
Fax: (414) 355-7499